

## COMPATIBILIDADE DE IMPRESSORAS COM TF MX92

HP DeskJet 3320	HP OfficeJet 3680 All-in-One	HP Photosmart 2610 all-in-one	HP PSC 1110
HP DeskJet 3325	HP OfficeJet 4110 All-In-One	HP Digital Copier Printer 410	HP PSC 1110v
HP DeskJet 3420	HP OfficeJet 4110v MFP	HP Fax 1240	HP PSC 1118
HP DeskJet 3425	HP OfficeJet 4110xi MFP	HP Fax 1240	HP PSC 1200
HP DeskJet 3520	HP Officejet 4215 All-in-One	HP Fax 1250	HP PSC 1205
HP DeskJet 3535	HP OfficeJet 4215v	HP Fax 1250	HP PSC 1209
HP DeskJet 3550	HP OfficeJet 4215xi	HP Photosmart 2710 all-in-one	HP PSC 1210 all-in-one
HP DeskJet 3650	HP OfficeJet 4300 All-in-One	HP Photosmart 5610 All-in-One	HP PSC 1210v all-in-one
HP Deskjet 3740	HP OfficeJet 4310	HP Photosmart 5610v All-in-One	HP PSC 1210xi all-in-one
HP Deskjet 3745	HP OfficeJet 4315	HP Photosmart 5610xi All-in-One	HP PSC 1310 All-In-One
HP DeskJet 3747	HP OfficeJet 4315 All-in-One	HP PhotoSmart 7150	HP PSC 1311 All-in-One
HP DeskJet 3843	HP OfficeJet 4315v	HP Photosmart 7260	HP PSC 1315 All-in-One
HP Deskjet 3845	HP OfficeJet 4315xi	HP PhotoSmart 7260v	HP PSC 1315v
HP DeskJet 3910	HP OfficeJet 4350	HP PhotoSmart 7260w	HP PSC 1315xi
HP DeskJet 3915	HP OfficeJet 4355 All-in-One	HP PhotoSmart 7350	HP PSC 1317
HP DeskJet 3918	HP OfficeJet 5500	HP Photosmart 7450	HP PSC 1340 All-in-One
HP DeskJet 3920	HP OfficeJet 5505 All-in-One	HP Photosmart 7450v	HP PSC 1350
HP DeskJet 3930	HP OfficeJet 5510 All-In-One	HP Photosmart 7450xi	HP PSC 1350 All-In-One
HP DeskJet 3930v	HP OfficeJet 5510v	HP PhotoSmart 7550	HP PSC 1355
HP DeskJet 3938	HP OfficeJet 5510xi	HP PhotoSmart 7660v	HP PSC 1401
HP DeskJet 3940	HP OfficeJet 5515	HP PhotoSmart 7660w	HP PSC 1402
HP DeskJet 3940v	HP OfficeJet 5600	HP PhotoSmart 7755	HP PSC 1403
HP DeskJet 450cbi	HP OfficeJet 5605	HP PhotoSmart 7760	HP PSC 1406
HP DeskJet 450ci	HP OfficeJet 5605z	HP PhotoSmart 7760v	HP PSC 1408
HP DeskJet 450wbt	HP OfficeJet 5608	HP PhotoSmart 7760w	HP PSC 1410 All-in-One
HP DeskJet 460c	HP OfficeJet 5610 All-in-One	HP PhotoSmart 7850	HP PSC 1410v All-in-One
HP DeskJet 460cb	HP OfficeJet 5610v All-in-One	HP PhotoSmart 7960	HP PSC 1410xi All-in-One
HP DeskJet 460wbt	HP OfficeJet 5610xi All-in-One	HP PhotoSmart 7960w	HP PSC 1415
HP DeskJet 460wf	HP OfficeJet 6110 All-In-One	HP Photosmart 8150	HP PSC 1417 All-in-One
HP DeskJet 5150	HP OfficeJet 6110xi	HP Photosmart 8150v	HP PSC 1510 All-in-One
HP DeskJet 5420v	HP OfficeJet 6200 All-in-One	HP Photosmart 8150xi	HP PSC 1600 All-in-One
HP DeskJet 5440	HP Officejet 6210 All-in-One	HP Photosmart 8450	HP PSC 1610 All-in-One
HP DeskJet 5440xi	HP OfficeJet 6300	HP Photosmart 8450v	HP PSC 2105
HP DeskJet 5442	HP OfficeJet 6300 All-in-One	HP Photosmart 8450xi	HP PSC 2108
HP DeskJet 5443	HP OfficeJet 6310 All-in-One	HP PhotoSmart C3100	HP PSC 2110 all-in-one
HP DeskJet 5550	HP OfficeJet 7210 All-in-One	HP PhotoSmart C3140	HP PSC 2110v all-in-one
HP DeskJet 5551	HP Officejet 7310 All-in-One	HP PhotoSmart C3150	HP PSC 2110xi all-in-one
HP DeskJet 5650	HP Officejet 7410 All-in-One	HP PhotoSmart C3180	HP PSC 2115
HP Deskjet 5740	HP OfficeJet J3680 All-in-One	HP PhotoSmart D7260	HP PSC 2150
HP DeskJet 5740xi		HP PhotoSmart Pro B8300	HP PSC 2170
HP DeskJet 5743		HP PhotoSmart Pro B8350	HP PSC 2171
HP DeskJet 5745			HP PSC 2175 All-In-One
HP DeskJet 5748			HP PSC 2175v
HP DeskJet 5850			HP PSC 2175xi
HP Deskjet 6540			HP PSC 2200
HP Deskjet 6540dt			HP PSC 2210 all-in-one
HP DeskJet 6540xi			HP PSC 2210v
HP DeskJet 6543			HP PSC 2210xi
HP Deskjet 6840			HP PSC 2350 All-in-One
HP Deskjet 6840dt			HP PSC 2355 all-in-one
HP DeskJet 9650			HP PSC 2410 Photosmart
HP Deskjet 9670			HP PSC 2510 Photosmart
HP Deskjet 9680			
HP DeskJet 9800			
HP DeskJet 9800d			
HP DeskJet D1330			
HP DeskJet D1360			
HP DeskJet D2330			
HP DeskJet D2360			
HP DeskJet D2430			
HP DeskJet D2445			
HP DeskJet D2460			
HP DeskJet F300 All-in-One			
HP DeskJet F340			
HP DeskJet F380			
HP DeskJet F2180			
HP DeskJet F4180			